

Operating instructions

Microcool

MC 250, MC 350, MC 600, MC 1200, MC 1200 W

Circulation chiller



LAUDA DR. R. WOBSE GMBH & CO. KG

Pfarrstraße 41/43

97922 Lauda-Königshofen

Germany

Phone: +49 (0)9343 503-0

Fax: +49 (0)9343 503-222

E-Mail: info@lauda.de

Internet: www.lauda.de

Translation of the original operating instructions

YAWD0033 from software version 1.46 with fill mode V03REV19 16/06/2015 ©LAUDA 2013

Table of contents

1	Safety.....	6
1.1	General safety instructions.....	6
1.2	Intended use.....	7
1.3	Foreseeable misuse.....	7
1.4	Modifications to the device.....	7
1.5	Heat transfer liquid.....	7
1.6	Materials.....	8
1.7	Hoses.....	8
1.8	Application area.....	8
1.9	Personnel qualification.....	8
1.10	Personal protective equipment.....	9
1.11	Structure of the safety instructions.....	9
2	Unpacking.....	11
3	Design and function.....	12
3.1	Device types.....	12
3.2	Design of the circulation chiller.....	13
3.3	Controls.....	17
3.3.1	Mains power switch.....	17
3.3.2	Display buttons.....	18
3.4	Function elements.....	19
3.4.1	LEDs for function display.....	19
3.4.2	Hydraulic circuit.....	19
3.4.3	Manometer.....	20
3.4.4	Level indicator.....	20
3.4.5	Refrigeration unit.....	20
3.4.6	Interfaces.....	21
3.5	Rating plate.....	22
3.6	Serial number.....	22
4	Before commissioning.....	23
4.1	EMC classification.....	23
4.2	Device Placement.....	24
4.3	External consumer.....	25
4.3.1	Tubes.....	25
4.3.2	Connecting external consumer.....	27
4.4	Cooling water.....	27
4.4.1	Cooling water requirements.....	27

Table of contents

4.4.2	Connecting cooling water.....	29
4.5	RS232 interface.....	30
4.5.1	Cable and interface test RS232.....	30
4.6	Alarm output 12N.....	31
5	Commissioning.....	32
5.1	LAUDA heat transfer liquids.....	32
5.2	Establishing power supply.....	33
5.3	Switching on device and filling with water.....	33
5.4	Setting pump pressure.....	36
6	Operation.....	37
6.1	Switching on the device.....	37
6.2	Default display and menu items.....	37
6.3	Screen displays.....	40
6.4	Specifying the setpoint temperature.....	40
6.5	Restricting temperature limit values.....	41
6.6	Configuring timer.....	42
6.7	RS232 interface.....	44
6.7.1	Configuring RS232 interface.....	44
6.7.2	Protocol.....	45
6.7.3	Write commands.....	46
6.7.4	Read commands.....	46
6.7.5	Error messages.....	47
6.8	Configuring alarm output.....	47
6.9	Inputting offset of the temperature sensor.....	48
6.10	Restoring the factory settings.....	49
7	Maintenance.....	50
7.1	General safety instructions.....	50
7.2	Maintenance intervals.....	50
7.3	Cleaning the device.....	51
7.4	Cleaning air-cooled condenser.....	51
7.5	Cleaning the water filter.....	52
7.6	Decalcification of the cooling water circuit.....	52
7.7	Checking the heat transfer liquid.....	53
8	Faults.....	54
8.1	Alarms, errors and warnings.....	54
8.2	Alarms overview.....	55
8.3	Warnings overview.....	55
9	Decommissioning.....	56

9.1	Draining the device.....	56
9.2	Draining condenser (only water-cooled devices).....	56
10	Disposal.....	58
10.1	Disposing of refrigerant.....	58
10.2	Device disposal.....	58
10.3	Disposing of packaging.....	58
11	Technical data.....	59
11.1	General data.....	59
11.2	Refrigerant unit.....	60
11.3	Hydraulic circuit.....	60
11.4	Voltage-dependent data.....	61
12	General.....	62
12.1	Copyright.....	62
12.2	Technical changes.....	62
12.3	LAUDA contact.....	62
12.4	EU conformity.....	62
13	Index.....	63

1 Safety

1.1 General safety instructions

- The equipment must only be operated for the intended use under the conditions stated in this operating manual. Any other type of operation is considered to be not-intended use and can impair the protection provided by the device.
- The operating manual is part of the device. The information in this operating manual must therefore be available in close vicinity to the device. Also store this copy of the operating manual carefully.



If you lose this operating manual, contact the LAUDA Constant Temperature Equipment service. The contact details can be found in ↗ Chapter 12.3 'LAUDA contact' on page 62.

Use of the device results in hazards from high or low temperatures, fire and from the use of electrical energy. The hazards of the device must be eliminated as much as possible by the design in accordance with the appropriate standards. Residual hazards are reduced using any of the following measures:

- If relevant, there are safety devices for the device. These devices are essential for the safety of the device. Their functionality must be ensured with appropriate maintenance activities.
The safety devices of the device are described in this "Safety" chapter.
- If relevant, there are warning symbols on the device. These symbols must always be observed.
The warning symbols on the device are described in this chapter "Safety".
- There are safety instructions in this operating manual. These instructions must always be observed.
- There are additional specific requirements for the personnel and for the personal protective equipment.
These requirements are described in this "Safety" chapter.



An overview of the authorised personnel and the protective equipment can be found in ↗ Chapter 1.9 'Personnel qualification' on page 8 and ↗ Chapter 1.10 'Personal protective equipment' on page 9.



Further information about the general structure of safety instructions can be found in ↗ Chapter 1.11 'Structure of the safety instructions' on page 9.

1.2 Intended use

Intended use

The present device is exclusively permitted to be used for tempering and delivering non-combustible heat transfer liquids in a closed circuit.

Non-intended use

The following applications are considered to be not-intended:

- medical applications
- in potentially explosive areas
- for tempering foodstuffs
- with a glass reactor without overpressure protection

1.3 Foreseeable misuse

Misuse of the device must always be prevented.

Among other things, the following uses are considered to be foreseeable misuse:

- Operation of the device without heat transfer liquid
- Incorrect connection of tubes
- Placement of the device on a tabletop surface, only permitted for MC 250 and MC 350
- Setting an incorrect pump pressure

1.4 Modifications to the device

Any technical modifications to the machine are prohibited. Service works may be carried out only by the LAUDA Constant Temperature Devices service or one of the service partners authorized by LAUDA.

1.5 Heat transfer liquid

- The device is exclusively designed for nonflammable heat transfer liquids in Class I according to DIN 12876-1.
- Heat transfer liquids are used for the temperature control. Only LAUDA heat transfer liquids are approved for the device. LAUDA heat transfer liquids are heat transfer liquids that have been tested and approved by the company LAUDA DR. R. WOBSE GMBH & CO. KG.

- In each case, the heat transfer liquids cover a specific temperature range. This temperature range must match the temperature range of your application.
- The use of heat transfer liquids can cause hazards from high or low temperatures and fire if certain temperature thresholds are exceeded or undercut or if the container breaks and there is a reaction with the heat transfer liquid .
The heat transfer liquid safety data sheet specifies all possible hazards and appropriate safety measures for handling the liquid. The safety data sheet must therefore be consulted for the intended use of the device.

1.6 Materials

All parts coming into contact with the heat transfer liquid are made of high quality materials suitable for the operating temperature. Stainless steel and temperature-resistant plastics are used.

1.7 Hoses

Only LAUDA hoses are permitted to be used for the external hydraulics circuit. LAUDA hoses are hoses that are approved by LAUDA DR. R. WOBSE GMBH & CO. KG. When selecting suitable hoses for the application, the permissible temperature range and the maximum permissible pressure must be particularly observed.

1.8 Application area

The device is exclusively permitted to be used in the following areas.

- Commercial area
- Indoor use, no outdoor installation

1.9 Personnel qualification

Operating personnel

Operating personnel are employees that have been instructed by technical staff in the intended use of the device according to the operating manual.

1.10 Personal protective equipment

Protective clothing

Protective clothing is required for certain activities. This protective clothing must comply with the legal requirements for personal protective equipment. Protective clothing should have long sleeves. Safety footwear is additionally required.

Protective gloves

CE protective gloves are required for certain activities. These protective gloves must comply with the legal requirements for personal protective equipment of the European Union.

Protective goggles

Protective goggles are required for certain activities. These protective goggles must comply with the legal requirements for personal protective equipment of the European Union.

1.11 Structure of the safety instructions

Danger

- A safety instruction of the type "Danger" indicates an **immediately hazardous** situation.
- This results in **death** or **severe, irreversible injuries** if the safety instruction is disregarded.

 DANGER! Type and source	
	Consequences in the case of non-compliance
	● Measure 1 ● Measure...

Warning

- A safety instruction of the type "Warning" indicates a **potentially hazardous** situation.
- This can result in **death** or **severe, irreversible injuries** if the safety instruction is disregarded.

 WARNING! Type and source	
	Consequences in the case of non-compliance
	● Measure 1 ● Measure...

Safety

Caution

- A safety instruction of the type "Caution" indicates a **potentially hazardous** situation.
- This can result in **minor, reversible injuries** if the safety instruction is disregarded.

 CAUTION! Type and source	
	Consequences in the case of non-compliance
	● Measure 1 ● Measure...

Notice

A "notice" warns about possible property or environmental damage.

 NOTICE! Type and source	
	Consequences in the case of non-compliance
	● Measure 1 ● Measure...

2 Unpacking



DANGER! Transport damage

Electric shock

- Inspect the device for transport damage before commissioning.
- Never put the device into operation if you have discovered any transport damage.

Personnel: ■ Operating personnel

1. Unpack the device.



Keep the original packaging of the device for later transport.

2. Inspect the device and the accessories immediately after delivery for completeness and transport damage.



If there is unexpected damage to the device or accessories, inform the carrier immediately so that a damage report is produced and a check of the transport damage can be made. Also inform LAUDA Constant Temperature Equipment Service immediately. Contact details can be found in ↗ Chapter 12.3 'LAUDA contact' on page 62.

Accessories included as standard

Device type	Designation	Quantity	Catalogue number
MC 600, MC 1200 (W)	¾" olive with ¾" union nut	2	EOA 004
All equipment	Operating manual	1	--

3 Design and function

3.1 Device types

The type designation of the equipment is composed of the following elements.

Element	Description
MC	Microcool
<number>, e.g. 600	Specification of the cooling capacity in watts
W	Device with water cooling This specification in the device type is optional. It identifies water-cooled devices.

Available device types

Device type	Description
MC 250	Air-cooled tabletop device with a cooling capacity of 250 watts
MC 350	Air-cooled tabletop device with a cooling capacity of 350 watts
MC 600	Air-cooled floor-standing device with a cooling capacity of 600 watts. The pump pressure can be adjusted using a bypass adjustment wheel.
MC 1200	Air-cooled floor-standing device with a cooling capacity of 1200 watts. The pump pressure can be adjusted using a bypass adjustment wheel.
MC 1200 W	Water-cooled floor-standing device with a cooling capacity of 1200 watts. The pump pressure can be adjusted using a bypass adjustment wheel.

3.2 Design of the circulation chiller

Front side MC 250, MC 350




Fig. 1: Overview of the front side

- 1 Filler neck with cover
- 2 Level indicator
- 3 Control panel
- 4 Front panel with ventilation openings
- 5 Four support feet

Rear side MC 250, MC 350




Fig. 2: Overview of the rear side

- 1 Pump connection, return
- 2 Overflow connection
- 3 Pump connection, outlet
- 4 Rating plate
- 5 RS232 interface
- 6 Alarm output
- 7 Drain plug
- 8 Mains cable
- 9 Ventilation openings

Front side MC 600, MC 1200 (W)




Fig. 3: Overview of the front side

- 1 Filler neck with cover
- 2 Level indicator
- 3 Control panel
- 4 Manometer
- 5 Front panel with ventilation openings
- 6 Four castors with locking brakes

Rear side MC 600, MC 1200 (W)




Fig. 4: Overview of the rear side

- 1 Bypass adjustment wheel
- 2 Pump connection, outlet
- 3 Pump connection, return
- 4 Overflow connection
- 5 Rating plate
- 6 Drain plug
- 7 RS232 interface
- 8 Alarm output
- 9 Mains cable
- 10 Ventilation openings
- 11 Supply of the water cooling
- 12 Return of the water cooling

Control panel




Fig. 5: Control panel

- 1 Display
- 2 LEDs
- 3 Display buttons
- 4 Mains power switch

3.3 Controls

3.3.1 Mains power switch

The mains power switch can be put in the following positions:

- In position [I], the device is switched on.
- In position [O], the device is switched off.

3.3.2 Display buttons




Fig. 6: Display buttons

- 1 UP arrow button
- 2 ENTER button
- 3 DOWN arrow button

Functions in the display of the device can be controlled using the display buttons.

- A selection in the display can be confirmed with the ENTER button.
- The UP and DOWN arrow buttons can be used to navigate in the display.

3.4 Function elements

3.4.1 LEDs for function display




Fig. 7: LEDs

- 1 Yellow LED
- 2 Blue refrigeration LED
- 3 Red error LED

Each device has three LEDs with the following functions:

- The yellow glycol LED lights if Kryo 30 is necessary as heat transfer liquid.
- The blue refrigeration LED indicates whether the refrigeration unit is active.
- The red error LED lights in the event of device faults.

3.4.2 Hydraulic circuit

Hydraulic circuit

The hydraulic circuit designates the circuit through which the heat transfer liquid flows.

The circuit basically consists of the following components:

- internal storage bath with heat transfer liquid
- pump for conveying the heat transfer liquid into the external consumer via the pump connections
- Starting with MC 600, devices are equipped with an adjustable bypass to be able to adapt the pump pressure to the requirements of the external consumer.

Pump

The devices are equipped with a magnetically coupled pressure pump.



Further information about the technical data of the pump and the pump characteristic curve can be found
👉 Chapter 11.3 'Hydraulic circuit' on page 60.

3.4.3 Manometer



Fig. 8: Manometer

The device types with bypass have a manometer for reading the set pump pressure. The pump pressure is regulated using the bypass adjustment wheel on the rear side.

3.4.4 Level indicator




Fig. 9: Level indicator

The fill level of the heat transfer liquid in the circuit can be read using the level indicator.

- The top arrow indicates the maximum liquid level of the machine.
- The bottom arrow indicates the minimum liquid level of the machine.

- 1 Maximum level
- 2 Minimum level

3.4.5 Refrigeration unit

The refrigeration unit includes the following components:

- **Compressor**
A hermetically sealed compressor is used in the refrigeration unit. The compressor is equipped with overload protection which trips on the compressor temperature and compressor current consumption.
- **Condenser**
Depending on the device type, an air-cooled or water-cooled condenser is used in the refrigeration unit. In air-cooled condensers, the condensation heat is discharged to the environment. The fresh air is sucked in through the front of the device using a fan, heated and discharged on the rear of the device. In water-cooled condensers, the condensation heat is discharged via cooling water.
- **Evaporator**
In the internal bath, heat is discharged using a pipe coil evaporator.



Technical information for the refrigeration unit can be found in ↗ Chapter 11.2 'Refrigerant unit' on page 60.

3.4.6 Interfaces

Note the following:

- The equipment connected to the low voltage inputs and outputs must have safe separation from dangerous voltages according to DIN EN 61140 such as by double or reinforced insulation according to DIN EN 60730-1 or DIN 60950-1.

RS232 interface

Specific functions of the device such as the setpoint temperature can be controlled with the RS232 interface using a PC. Thus, custom programs for controlling the device can be developed.



Further information about the connection and configuration can be found in ↗ Chapter 6.7.1 'Configuring RS232 interface' on page 44.

Alarm output

Changeover contact which switches in the event of a device fault. For example, faults can be registered on a system.



Using the display, it can be set in which fault situations a signal is output via the interface.

3.5 Rating plate

LAUDA Made in Germany	
Type:	MC 250
Catalog No. / Bestell Nr.	LWM 118
Serial No. / Serien Nr.	LWM118-15-0001
Refrigerant / Kältemittel I	R134a*
Filling charge / Füllmenge I	85 g
PS high pressure / Hochdruck I:	21 bar
PS low pressure / Niederdruck I:	10 bar
Refrigerant / Kältemittel II	
Filling charge / Füllmenge II	
PS high pressure / Hochdruck II:	
PS low pressure / Niederdruck II:	
Voltage / Spannung:	230 V; 50 Hz
Power consumption / Leistungsaufnahme	0,23 kW
Protection class / Schutzart	IP 32
Fuse / Sicherung	T15 A
Klasse nach DIN 12876-1	I / NFL
* = HFC/HFKW Kyoto Protocol	
  LAUDA DR. R. WOBSEY GMBH & CO. KG 97922 Lauda-Königshofen, Pfarrstr. 41/43, Germany	

Fig. 10: Rating plate

The rating plate information is explained in detail in the following table. Certain information is dependent on installed device options. This information is noted with an appropriate suffix.

Specification	Description
Type	Device type
Catalogue No.	Catalogue number of the device
Serial No.	Serial number of the device
Refrigerant I	Refrigerant that is used in the compressor of the device
Fill quantity I	Fill quantity of the refrigerant
PS high pressure I	maximum permitted operating pressure on the refrigerant high pressure side (compressor, condenser)
PS low pressure I	maximum permitted operating pressure on the refrigerant low pressure side (expansion, evaporation)
Voltage	Device must only be connected to this voltage and frequency
Power consumption	Power consumption of the device during operation
Protection rating	IP protection rating of the device
Fuse	Fuse used in the device
Class according to DIN 12876-1	German standard for electrical laboratory equipment

3.6 Serial number

The serial number of a LAUDA device has the following structure:

- LAUDA catalogue number
- Year of manufacture
The year is indicated with two digits.
- Sequential number of the device in the year of manufacture.
The sequential number is a four-digit number.

This information is displayed in the format <catalogue number>-<year of manufacture>-<sequential number>.

An example for Microcool devices: LWM118-13-0130.

4 Before commissioning

4.1 EMC classification

Approval of the equipment according to EMC classification

Countries	EMC Class
Europe	Class A This classification has been made according to the EMC standard DIN EN 61326-1 (corresponds to VDE 0843-20-1).
USA	Class A This classification has been made according to the FCC (Federal Communications Commission) regulations, Section 15.
Canada	Class A This classification has been made according to the ICES-003 (Interference Causing Equipment Standards) and NMB-003 regulations.

Instructions for machines, Europe

EMC classification of the equipment:

- Class A: Operation only on mains power supplies without connected residential areas.
- Class B: Operation on mains power supplies with connected residential areas.

In the case of unfavourable mains conditions, disruptive voltage fluctuations can occur.

Instructions for Class A digital device, USA

"This equipment has been tested and found to comply with the limits for Class A digital device, pursuant to Part 15 of the FCC (Federal Communication Commission) Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense."

Instructions for Class A digital device, Canada

"This Class A digital apparatus complies with Canadian ICES-003" (ICES = Interference Causing Equipment Standards).

« Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada ».

4.2 Device Placement

Very specific placement conditions are applicable for the equipment. These placement conditions are specified in the technical data of the device for the most part.



Further information about the technical data can be found in ↗ Chapter 11.1 'General data' on page 59.

Additional placement conditions are described below.

- Toxic vapours can be produced depending on the heat transfer liquid used and type of operation. Ensure sufficient extraction of the vapours.
- Observe the requirements of the device for electromagnetic compatibility (EMC).
- Do not cover the ventilation openings.



Further information about EMC requirements can be found in ↗ Chapter 4.1 'EMC classification' on page 23.



WARNING!
Rolling away, falling over of the device

Impact, crushing

- Do not tilt the device.
- Place the device on a level, non-slip surface with sufficient load bearing capacity.
- Engage the castor brake when setting up the device.
- Do not place any heavy parts on the device.

1. Place the device at a suitable location in the room.
 - Place tabletop devices on a suitable table. Support the device for this by reaching under the device.
 - Place floor-standing devices on a suitable base.



Floor-standing devices can be moved. Release the locking brakes of the castors for this by pressing the [Off] lever downwards.



Several devices can be positioned next to each other.

2. Lock the castors of the device for floor-standing devices. Press the [On] lever downwards to lock.

4.3 External consumer

4.3.1 Tubes



CAUTION!
Discharge of heat transfer liquid during operation caused by use of unsuitable hoses

Frostbite

- Use hoses with temperature resistance that is appropriate for the operating temperature range of the device.



CAUTION!
Contact with cold hoses

Frostbite

- Use insulated hoses for temperatures below 0 °C.



The tubes specified below can be used for all heat transfer liquids that are approved for the devices.



Further information about the pump connections of the individual devices can be found in ↗ Chapter 11.3 'Hydraulic circuit' on page 60.

Approved tubes, adapters and tube clamps

Tubes, not insulated

Type	Olive	maximum permissible pressure	Internal Ø in mm	External diameter in mm	Temperature range in °C	Catalogue number
EPDM tube	10 mm	Devices with maximum pump pressure of < 1 bar	9	11	10 — 90	RKJ 111
EPDM tube	$\frac{1}{2}$ " (13 mm)	Devices with maximum pump pressure of < 1 bar	12	14	10 — 90	RKJ 112
Rubber tube with fabric reinforcement	$\frac{1}{2}$ " (13 mm)	up to 10 bar	13 ($\frac{1}{2}$ ")	19	-40 — 100	RKJ 031
Rubber tube with fabric reinforcement	$\frac{3}{4}$ " (19 mm)	up to 10 bar	19 ($\frac{3}{4}$ ")	27	-40 — 100	RKJ 032

Before commissioning

Tubes, insulated at the factory

Type	Pump connections	Application area	Internal Ø in mm	Insulation in mm	Temperature range in °C	Catalogue number
EPDM tube, insulated	Olive 13 mm, M16 x 1	Devices with maximum pump pressure of < 1 bar	12	9	-35 — 90	LZS 021

Insulation tubes for subsequent insulation, length 1 m

Insulation catalogue number	Temperature range in °C	Internal Ø in mm	Wall thickness in mm	Suitable for tube
RKJ 058	-50 — 105	19	17.5	RKJ 112
RKJ 024	-50 — 110	16	8	RKJ 112
RKJ 009	-50 — 110	23	8.5	RKJ 031
RKJ 013	-50 — 110	29	8.5	RKJ 032

Adapters, suitable for MC 600 and MC 1200 (W)

Description	Description	Catalogue number
Olive	$\frac{3}{4}$ " union nut, $\frac{1}{2}$ " olive	LWZ 016
Olive	$\frac{3}{4}$ " union nut, 10 mm olive	LWZ 040

Tube clamps

Material	Ø from to in mm	Catalogue number
Stainless steel	10 — 16	EZS 012
Stainless steel	12 — 22	EZS 013
Stainless steel	20 — 32	EZS 015

4.3.2 Connecting external consumer

	CAUTION! Discharge of heat transfer liquid during operation caused by open consumer
	Electric shock, frostbite
	Only use closed consumers.

	CAUTION! Bursting of the external hydraulic circuit due to overpressure
	Impact, cutting, frostbite
	Lay hoses so that they do not kink.

Note the following:

- Temperature control hoses: Always use the largest possible diameters and shortest possible hose lengths in the external liquid circuit.
If the temperature control hose diameter is too small, a temperature drop between device and external consumer occurs due to flow rate too low. In this case, increase or lower the temperature accordingly.
- Secure the temperature control hoses with hose clamps.
- If the external consumer is at a higher level than the device, emptying of the external volume can occur if the pump is stopped and there is ingress of air in the external liquid circuit even for closed circuits. In this case, you risk device overflow.
- In the event of hose rupture, cold liquid can escape and become a danger for persons and material.

4.4 Cooling water

4.4.1 Cooling water requirements

This section is relevant for the following:

- For water-cooled devices

Before commissioning

General requirements

There are specific requirements for the cooling water concerning its purity. In accordance with the cooling water requirements, a suitable process for treatment and maintenance of the water must be used. The condenser and the complete cooling water circuit can be clogged, damaged and leak due to unsuitable cooling water. Extensive consequential damage to the complete refrigerant circuit can occur. The cooling water quality is dependent on the local conditions.

- Free chlorine, e.g. from disinfectants and water containing chloride results in pitting corrosion in the cooling water circuit.
- Distilled, deionised or demineralised water is not suitable due to its corrosive properties and results in corrosion in the cooling water circuit.
- Seawater is not suitable due to its corrosive properties and results in corrosion in the cooling water circuit.
- Water containing iron and iron particles in the water result in rust formation in the cooling water circuit.
- Hard water is not suitable for cooling due to the high lime content and results in calcification in the cooling water circuit.
- Cooling water with suspended matter is not suitable.
- Untreated, not purified water, e.g. river or cooling tower water is not suitable due to its microbiological content (bacteria) which can settle in the cooling water circuit.

Suitable cooling water quality

Data	Value	Unit
pH value	7.5 – 9.0	
Sulphates [SO ₄ ²⁻]	< 70	mg/l
Hydrogen carbonate [HCO ₃ ⁻] / Sulphates [SO ₄ ²⁻]	> 1.0	
Water hardness (alkaline earth ions content)	0.71 - 1.52	mmol/l
Hydrogen carbonate [HCO ₃ ⁻]	70 – 300	mg/l
Conductivity	10 - 500	µs/cm
Chlorides (Cl ⁻)	< 50	mg/l
Sulphite (SO ₃ ²⁻)	< 1	mg/l
Free chlorine gas (Cl ₂)	< 1	mg/l
Nitrates (NO ₃ ⁻)	< 100	mg/l
Ammonia (NH ₃)	< 2	mg/l
Iron (Fe), dissolved	< 0.2	mg/l
Manganese (Mn), dissolved	< 0.1	mg/l
Aluminium (Al), dissolved	< 0.2	mg/l
Free, aggressive carbonic acid (CO ₂)	< 5	mg/l

Data	Value	Unit
Hydrogen sulphide (H ₂ S)	< 0.05	mg/l
Algae growth	not permitted	
Suspended matter	not permitted	

4.4.2 Connecting cooling water

This section is relevant for the following:

- For water-cooled devices

Specification	Value
Maximum cooling water pressure	6 bar
Differential pressure cooling water Δp	1 — 6 bar
Cooling water temperature	approx. 15 °C recommended, 10 — 30 °C permissible (with performance limitations)

Note the following:

- Fix the cooling water tubes in place using tube clamps.
- Fix the supply tube of the water cooling in place in the sink area to prevent uncontrolled sliding, also in the event of pressure surges.
Fix the supply tube of the water cooling in place in the sink area so that spraying out of hot cooling water is not possible.
- Prevent kinking or squeezing of the tubes.
- We recommend using a leak detector with water shut-off to prevent damage due to cooling water system leaks.
- Ensure that the cooling water meets the required criteria.
- In the case of leaks in the condenser, there is the danger that refrigerator oil and refrigerant from the refrigerant circuit of the device can get into the cooling water. Comply with all applicable legal provisions and the requirements of the water supply companies at the operating site.

4.5 RS232 interface

4.5.1 Cable and interface test RS232

Computer					Thermostat		
Signal	9-pin Sub-D female connector		25-pin Sub-D female connector		9-pin Sub-D female connector		Signal
	with hardware handshake	without hardware handshake	with hardware handshake	without hardware handshake	with hardware handshake	without hardware handshake	
RxD	2	2	3	3	2	2	TxD
TxD	3	3	2	2	3	3	RxD
DTR	4		20		4		DSR
Signal Ground	5	5	7	7	5	5	Signal Ground
DSR	6		6		6		DTR
RTS	7		4		7		CTS
CTS	8		5		8		RTS

Note the following:

- With hardware handshake: Use a straight-through and not a null modem cable for connecting a thermostat to the PC. The RS232 interface can be connected directly to the PC using a straight-through cable.
- Without hardware handshake: Set the corresponding operating mode on the PC. Use shielded connection cables. Connect shield to connector case. The cables must be galvanically isolated from the rest of the electronics. Do not connect unassigned pins.
- The RS232 interface can be easily checked on a connected PC with the Microsoft Windows operating system.
For Windows® 3.11 using the "Terminal" program.
For Windows® 95/98/NT/XP using the "HyperTerminal" program.

"HyperTerminal" is no longer part of the operating system for the Windows Vista, Windows 7 and Windows 8 operating systems.

- The RS232 interface can be addressed using the LAUDA Wintherm Plus control and programming software (catalogue number LDSM2002).
- Freeware terminal programs can be found on the World Wide Web. These programs provide similar functions to those of "HyperTerminal" (for example PuTTY). Search request "serial port terminal program".

4.6 Alarm output 12N

Available functions

Function	Description
<i>Alarm output</i>	--
<i>Alarm and standby</i>	for on-site return flow protection

- Max. 30 V DC; 0.2 A




Fig. 11: Flange connector (front) in idle state

- 1 Normally open contact
- 2 Centre
- 3 Normally closed contact

Front view of the flange connector or of the coupling socket on the solder side

Idle state

- The device is in idle state when it is switched off and in the case of failure.
- Pins 1 and 2 are open.
- Pins 3 and 2 are closed.

GO state

- The device is in GO state immediately after switching on and during normal operation without faults.
- Pins 1 and 2 are closed.
- Pins 3 and 2 are open.

Note the following:

- The equipment connected to the low voltage inputs and low voltage outputs must have safe separation from dangerous voltages according to DIN EN 61140. For example, using double or reinforced insulation according to DIN EN 60730-1 or DIN 60950-1.
- Only use shielded connection cables. Connect shield to connector case. Cover unused plug connections with protective caps.

5 Commissioning

5.1 LAUDA heat transfer liquids

Note the following:

- The heat transfer liquids each cover a recommended temperature range and must be suitable for the temperature range of your application.
- At the lower limit of the temperature range, the heat transfer liquid becomes more viscous and influences temperature constancy, pump power and cooling capacity. The formation of vapours and odours increases in the upper range. Therefore, only use all of the temperature range if required. Particularly with Aqua 90 (water), ice forms which can result in destruction of the device.
- Never use contaminated or degenerated heat transfer liquid.
- You can request the safety data sheets of the heat transfer liquid at any time if required.

Approved heat transfer liquids

LAUDA designation	Chemical designation	Temperature range in °C	Viscosity (kin) in mm ² /s (at 20 °C)	Viscosity (kin) in mm ² /s for temperature	Container size Catalogue number		
					5 l	10 l	20 l
Kryo 30	Mono ethylene glycol / water	-30 — 90	4	50 at -25 °C	LZB 109	LZB 209	LZB 309
Aqua 90	decalcified water	5 — 90	1	—	LZB 120	LZB 220	LZB 320

Note the following for Kryo 30:

- The water content reduces during long operating with higher temperatures and the mixture becomes flammable (flame point 128 °C). Check the mixture ratio using a hydrometer.

Heat transfer liquid water

- The alkaline earth ions content (hardness) of the water must be between 0.71 mmol/l and 1.42 mmol/l (equivalent to 4.0 and 8.0 °dH). Harder water results in lime deposits in the device.
- The pH value of the water must be between 6.0 and 8.5.
- Distilled, deionised, demineralised (DM) water or seawater must not be used due to the corrosive properties. Ultra-pure water and distillates are suitable as medium after addition of 0.1 g soda (Na₂CO₃, sodium carbonate) per litre of water.
- Any chlorine content in the water must be strictly avoided. Do not add any chlorine to the water. Chlorine is contained, for example, in cleaning agents and disinfectants.

- The water must be free of impurities. Water containing iron is unsuitable due to rust formation and untreated river water is unsuitable due to algae formation.
- The addition of ammonia is not permitted.

5.2 Establishing power supply

Personnel: ■ Operating personnel

!

NOTICE!
Use of unauthorised mains voltage or mains frequency

Device damage
● Compare the rating plate with available mains voltage and mains frequency.

- Also note the following:
- The mains plug of the device provides a mains power disconnection component. The mains plug must be easily recognisable and easily accessible.
 - Only connect the device to an earthed (PE) power socket.

5.3 Switching on device and filling with water

Filling mode

The device has a software program (starting from and including software version 1.46) that supports the operator for filling the temperature control device. If the fill level is too low, the Fill mode is started immediately after switching on the device. *FILL* is shown on the display and the level indicator is illuminated. The pump and the refrigerant unit are not started.

Personnel: ■ Operating personnel

Protective equipment: ■ Protective goggles
 ■ Protective clothing
 ■ Protective gloves

!

NOTICE!
Overheating of the compressor

Device damage
● Never operate water cooled device without cooling water.



NOTICE! Overheating of the pump

Device damage

- Never operate device without heat transfer liquid.



DANGER! Use of incorrect heat transfer liquid

Fire

- Select a heat transfer liquid with a temperature range 20 K above the temperature range of the application.



WARNING! Overflow of heat transfer liquid

Electric shock

- Ensure that the device is not overfilled. Note the level indicator and the thermal volume expansion of the heat transfer liquid.



WARNING! Spraying of heat transfer liquid

Electric shock

- Avoid spraying heat transfer liquid. Use a funnel for filling.

You have already connected the external consumer as described in chapters ↗ Chapter 4.3.1 'Tubes' on page 25 and ↗ Chapter 4.3.2 'Connecting external consumer' on page 27.



When using pressure-sensitive consumers, note chapter ↗ Chapter 5.4 'Setting pump pressure' on page 36.

1. Close the drain plug. For this, turn the plug clockwise as far as the stop.
2. Attach a suitable tube to the overflow connection of the device.



The permitted tube diameter for the overflow must be complied with. Further information about the suitable tube diameter can be found in the technical data ↗ Chapter 11.3 'Hydraulic circuit' on page 60.

3. Insert this tube into a suitable canister to collect overflowing heat transfer liquid.



Running dry of the consumer can also occur in a closed temperature control circuit with consumer at a higher level in the case of stopped pump and ingress of air into the temperature control circuit (for example, a not completely closed or defective bleed valve). Match the size of the overflow container to this if possible.

Fill level sufficient

4. Switch on the device using the mains power switch.
 - A signal tone sounds. The software version is shown on the display. The actual temperature is shown on the display afterwards.

The temperature control device starts operation; the pump is started.

Depending on the specified setpoint temperature, the refrigerant unit is started after 2 minutes at the earliest. The blue LED lights if the refrigerant unit is active.

Fill level too low (Low Level)

5. Switch on the device using the mains power switch.
 - A signal tone sounds. The software version is shown on the display. *FILL* is shown on the display afterwards. In the case of Low Level, the pump and the refrigerant unit are not started.

Fill the device with heat transfer liquid.

6. Carefully pull up the cover of the filler neck; do not turn.
7. Fill the heat transfer liquid into the filler neck carefully. Monitor the level indicator. Fill the device up to the maximum fill level.



If necessary, use a funnel for the filling.



The level indicator must not be above the maximum fill level.

8. Press the **Enter button** when the fill level is at its maximum or sufficient.
 - The pump starts. The actual temperature is shown on the display. The fill level drops as the consumer is being filled.

Fill level drops

9. Top up the heat transfer liquid carefully as the consumer is now being filled. If the fill level drops too far, the device automatically goes into the FILL mode and the pump and refrigerant unit are switched off. Continue with the filling until operation without problems is possible. Monitor the level indicator for this.
10. Press the cover carefully into the filler neck.

5.4 Setting pump pressure

For devices with bypass (MC 600, MC 1200 and MC 1200 W), the pump pressure can be set using a control valve on the rear side of the device. Individual setting of the pump pressure is possible with this when using pressure-sensitive external consumers.

Personnel: ☒ Operating personnel



CAUTION! Bursting of the external consumer

Scalding, impact, cutting

- A bypass regulator is provided to set the pump pressure (starting from MC 600).
- For consumers with a maximum permissible operating pressure below the maximum pressure of the pump, use a safety valve for protection. This safety valve must be installed in the outlet of the device.

1. To reduce the pump pressure, turn the bypass adjustment wheel anticlockwise until the maximum permitted pressure for the external consumer is reached.



Monitor the display on the manometer for this.

2. To increase the pump pressure, turn the bypass adjustment wheel clockwise until the required pressure for the external consumer is reached.

6 Operation

6.1 Switching on the device

 NOTICE! Overheating of the compressor	
	Device damage
	● Never operate water cooled device without cooling water.

 NOTICE! Overheating of the pump	
	Device damage
	● Never operate device without heat transfer liquid.

Personnel: ■ Operating personnel

- Switch on the device using the mains power switch.
 - ▶ A signal tone sounds. The software version is shown on the display. The actual temperature is shown on the display afterwards.

The temperature control device starts operation; the pump is started.

Depending on the specified setpoint temperature, the refrigerant unit is started after 2 minutes at the earliest. The blue LED lights if the refrigerant unit is active.
- Depending on the size of the consumer, heat transfer liquid must be refilled if necessary. Monitor the level indicator for this.



Further information about refilling heat transfer liquid can be found in ↗ Chapter 5.3 'Switching on device and filling with water' on page 33.

6.2 Default display and menu items

- Press the ENTER button to reach the menu items from the default display of the actual temperature.



If no button has been pressed for longer than 4 seconds, you exit from the menu item or input window.

- Scroll from menu item to menu item using the arrow buttons.
- Press the ENTER button at the selected menu item.
 - ▶ The display flashes.

4. The value or the setting can be changed using the arrow buttons.
5. The changed value or setting is applied immediately by pressing the ENTER button.



If no button has been pressed for longer than 4 seconds, changed values or settings are applied automatically and you exit from the menu item or input window.




Fig. 12: Menu

6.3 Screen displays

Default display




Fig. 13: Default display

The default display is the indication shown in the screen if no other operations such as configuring settings are being performed. The actual temperature of the machine is shown in the default display.

Menu

The machine menu with possible settings can be invoked using the ENTER button.



Further information about the menu structure and the menu navigation can be found in ↗ Chapter 6.2 'Default display and menu items' on page 37.

Editing display

The display flashes when a menu item in the screen has been selected. The setting can now be made. The value entered is applied when the setting is confirmed.

6.4 Specifying the setpoint temperature

Relationship between temperature setpoint and temperature limit values

You specify a setpoint for the temperature control. This value specifies to which temperature the heat transfer liquid will be cooled. The upper and lower temperature limit values of the device have been set to the default values 45.0 °C and 5.0 °C. The temperature limits define the temperature range of your application, i.e. in which range any temperature control can take place. A warning is output by the device if the temperature is outside the limits. This range is necessary so that no unnecessary warnings are output during transient conditions of the temperature regulation. The default values can be limited subsequently depending on the heat transfer liquid.

For operation of the device with Aqua 90, the temperature setpoint must not be set smaller than 5 °C. Also use the lower temperature limit value *Lo* ↗ 'Lower temperature limit value' on page 42 and set this to 3 °C so that a warning is output for lower temperatures.

The yellow LED on the device lights if any temperature setpoint or actual temperature is less than 5 °C. It warns about incorrect use of the heat transfer liquid and consequential damage to the device.



If the device is operated with liquid temperatures below 5 °C, Kryo 30 (glycol / water) must be used in the device as heat transfer liquid.



Fig. 14: Setpoint input

Personnel: Operating personnel

1. Select the menu item for specifying the temperature setpoint.
2. Specify the setpoint.



If the entered setpoint is outside the specified temperature limit values, the value cannot be adopted. Editing mode is active. An audible signal is also output. You can input the setpoint again.

3. Confirm with the ENTER button.

6.5 Restricting temperature limit values

The range of the temperature limit values must be restricted for safety reasons. These two values depend on the heat transfer liquid used. The default settings of 45.0 °C and 5.0 °C stored in the device cannot be changed.

Practical temperature limit values are:

Aqua 90 - Set the range to the values 42 °C and 3 °C.

Kryo 30 (water / glycol) - Set the range to the values 42 °C and -12 °C.



By adjusting the temperature limit values, the configurable setpoint range is automatically limited to as 2 °C below the upper temperature limit and 2 °C above the lower temperature limit.

Upper temperature limit value




Fig. 15: Upper limit value

Personnel: Operating personnel

1. Select the menu item for the upper temperature limit value.
2. Confirm with the ENTER button.
3. Specify the upper limit value.



The maximum value of the upper limit is 45 °C.

4. Confirm with the ENTER button.

Lower temperature limit value



Fig. 16: Lower limit

Personnel: ■ Operating personnel

1. Select the menu item for the lower temperature limit value.
2. Confirm with the ENTER button.
3. Specify the lower limit value.



The minimum value of the lower limit is 5 °C when using Aqua 90 and -15 °C when using Kryo 30.

4. Confirm with the ENTER button.

6.6 Configuring timer

The integrated timer can be used for switching the device on and off automatically. The timer can be viewed and configured during normal operation of the device.

Special features of the timer

- The timer is configured using a number of hours and minutes in the format hh.mm. The first two digits represent the number of hours and the last two are the minutes. The timer can be set to a maximum of 99 hours and 59 minutes.
- The timer is only active while the machine is switched on. If the machine is switched off using the mains power switch during the running time of the timer, the timer is reset.

Functions for automatic switching off - Auto-Shut-Down

- If Auto-Shut-Down of the timer is active, the current actual temperature on the display is shown with a flashing decimal point.
- If Auto-Shut-Down is invoked using the corresponding menu item, the remaining time, for example 05.30, is shown flashing. If Auto-Shut-Down is deactivated, 00.00 is shown flashing.
- Once the time for Auto-Shut-Down has elapsed, the device is not switched off completely but switched to standby. Standby means all components of the device are switched off and only the display of the device is still supplied with power.

Functions for automatic switching on - Auto-Start

- If Auto-Start of the timer is configured, the device switches to standby and Auto-Start is active immediately. If any Auto-Shut-Down is active, the Auto-Start is not active until after completion of the Auto-Shut-Down.
- If Auto-Start is active, the remaining time until the automatic start is shown on the display. An audible signal is also output during the complete last minute before starting the device.

Configuring Auto-Shut-Down




Fig. 17: Auto-Shut-Down

1. Select the menu item for specifying the Auto-Shut-Down.
2. Confirm with the ENTER button.
3. Specify the time until the device should be switched to standby.



Wait for approx. 4 seconds if you would not like to apply the specified value. The screen automatically returns to the default display.

4. Confirm with the ENTER button.



The value must be confirmed within 4 seconds after the last input. Otherwise the screen returns to the default display.

- The device will be switched to standby after the time entered. This is shown on the display as follows.

5. Auto-Start can now be configured before the expiry of Auto-Shut-Down to switch the device on again afterwards after a specified time. Otherwise you can start the device manually by pressing the ENTER button.




Fig. 18: Standby

Configuring Auto-Start




Fig. 19: Auto-Start



CAUTION! Automatic device start using the auto-start timer

Frostbite, risk of injury, device damage

- Before using the auto-start timer, ensure that all preparations for the intended use have been made.

1. Select the menu item for specifying the Auto-Start.
2. Confirm with the ENTER button.
3. Specify the time until the device should be switched on again.



If no Auto-Shut-Down is configured for the device, the device is switched directly into standby with the confirmation.



Wait for approx. 4 seconds if you would not like to apply the specified value. The screen automatically returns to the default display.

4. Confirm with the ENTER button.



The value must be confirmed within 4 seconds after the last input. Otherwise the screen returns to the default display.

Displaying and editing remaining time

1. Select the menu item for the Auto-Shut-Down or Auto-Start.
2. Confirm with the ENTER button.
 - The remaining time is displayed.
3. You have the following options:
 - Wait approx. 4 seconds if you only want to display the remaining time. The default display is shown again.
 - To edit the remaining time, set the time accordingly. Confirm with the ENTER button.

Reset

1. Select the menu item for the Auto-Shut-Down or Auto-Start.
2. Input 00.00.
3. Confirm with the ENTER button.



The value must be confirmed within 4 seconds after the last input. Otherwise the screen returns to the default display.

Restart manually

If the device has been switched to standby using Auto-Shut-Down and no Auto-Start is configured, the device can be switched on again manually.

1. Press the ENTER button to switch the device on again.



This function is only available if no Auto-Start is active.

6.7 RS232 interface

6.7.1 Configuring RS232 interface

The baud rate for the RS232 interface can be configured using the display.




Fig. 20: RS232 interface

Personnel: ■ Operating personnel

- 1. Select the menu item for configuration of the RS232 interface.
- 2. Select the appropriate baud rate.

The following baud rates can be selected:

- 2.4
- 4.8
- 9.6
- 19.2

 *The hundreds and thousands digits are not visible on the display.*

- 3. Confirm with the ENTER button.

 *Your input is applied automatically after approx. 4 seconds.*

6.7.2 Protocol

RS232 protocol

Note the following:

- The interface operates with 1 stop bit, no parity bit and 8 data bits.
- Selectable transmission speed: 2400, 4800, 9600 (factory setting) or 19200 baud.
- The RS232 interface can be operated with or without hardware handshake (RTS/CTS).
- The command from the computer must be terminated with CR, CRLF or LFCR.
CR = Carriage Return (hex: 0D); LF = Line Feed (hex: 0A)
- The response from the thermostat is always terminated with CRLF.

Example for setpoint transfer of 30.5 °C to the thermostat.

Computer	Thermostat
"OUT_SP_00_30.5"CRLF	
	"OK"CRLF

Operation

6.7.3 Write commands

The write commands are data specifications to the thermostat.

Command	Meaning
OUT_SP_00_XXX.XX	Setpoint transfer with max. 3 digits before the decimal point and max. 2 digits afterwards
OUT_SP_04_XXX	[Hi] Upper limit of flow temperature
OUT_SP_05_XXX	[Lo] Lower limit of flow temperature
START	Switches on device (from standby)
STOP	Switches device to standby (pump, refrigeration unit off).

Note the following:

- For "_", " " (space character) is also permitted.
- Response from the thermostat "OK" or "ERR_X" in the case of an error.

Permitted data formats

-XXX.XX	-XXX.X	-XXX.	-XXX	XXX.XX	XXX.X	XXX.	XXX
-XX.XX	-XX.X	-XX.	-XX	XX.XX	XX.X	XX.	XX
-X.XX	-X.X	-X.	-X	X.XX	X.X	X.	X
-.XX	-.X	.XX	.X				

6.7.4 Read commands

The following read commands are data requests to the thermostat.

Command	Meaning
IN_PV_00	Query of the bath temperature (outlet temperature)
IN_SP_00	Query of the temperature setpoint
IN_SP_04	Query of the outlet temperature limit Hi
IN_SP_05	Query of the outlet temperature limit Lo
TYPE	Query of the device type (response = "MC").
VERSION	Query of the software version number

Command	Meaning
STATUS	Query of the device status, 0 = OK, -1 = fault
STAT	Query for the fault diagnosis, response: XXXXXXXX; X = 0 no fault, X = 1 fault Character 1 = error Character 2 = not assigned Character 3 = not assigned Character 4 = not assigned Character 5 = low level Character 6 = not assigned Character 7 = not assigned

Note the following:

- For "_", " " (space character) is also permitted.
- Unless otherwise specified for the command, the reply is always in fixed decimal format "XXX.XX" or "-XXX.XX" for negative values or "ERR_X".

6.7.5 Error messages

The error messages of the modules are described in the following.

Error	Description
ERR_2	Incorrect input (e.g. buffer overflow)
ERR_3	Incorrect command
ERR_5	Syntax error in the value
ERR_6	Impermissible value
ERR_32	The upper temperature limit is less than or equal to the lower temperature limit.

6.8 Configuring alarm output

In the case of an alarm or error, an electrical signal is output via the alarm output of the device as default. However, you can also configure that a signal will also be output in the case of a warning.



Fig. 21: Alarm output




Fig. 22: Option error and alarm



Fig. 23: Option with additional warning

Personnel: ■ Operating personnel

1. Select the menu item for configuring the alarm output.

2. Select the following option for the output of an electrical signal for alarms and errors.

3. Select the following option for the additional output of an electrical signal for warnings.



Wait for approx. 4 seconds if you would not like to apply the specified value. The screen automatically returns to the default display.

4. Confirm with the ENTER button.



The value must be confirmed within 4 seconds after the last input. Otherwise the screen returns to the default display.

6.9 Inputting offset of the temperature sensor



The calibration overwrites the factory calibration.

If any temperature difference is discovered when checking the device with a reference thermometer, the offset (additive part of the characteristic curve) of the internal measurement chain can be adjusted using the *CAL* menu item.

A calibrated reference thermometer (e.g. from the LAUDA DigiCal series) with the required degree of accuracy is required. Otherwise the factory calibration should not be changed.

The reference thermometer must be installed in the flow of the device in accordance with the specifications in the calibration certificate.



Fig. 24: Calibrating temperature sensor

Personnel: ■ Operating personnel

1. Select the menu item CAL.
2. Enter the temperature value read from the reference thermometer at the device.
3. Keep the ENTER button pressed for approx. 3 seconds afterwards.
 - The display shows *donE*. The new value has been applied.

6.10 Restoring the factory settings

Execute this menu item if you would like to restore the factory settings stored in the device.

- The range of the temperature limit values is reset to 45 °C and 5 °C.
- The timers are reset to *00.00*.
- The signal output at the alarm output is reset to *alarms and faults*.
- The baud rate is reset to *9600 baud*.

Personnel: ■ Operating personnel



Fig. 25: Factory settings

1. Select the menu item (dEF) for restoring the factory settings.
2. Confirm with the ENTER button.
3. Keep the ENTER button pressed for approx. 3 seconds afterwards.
 - The display shows *donE*. The factory settings have been restored.

7 Maintenance

7.1 General safety instructions

 DANGER! Contact with live or moving parts	
	Electric shock, impact, cutting, crushing
	● The device must be disconnected from the mains power supply before any maintenance work. ● Repairs must only be carried out by specialists.
 CAUTION! Contact with hot / cold device parts, accessories and heat transfer liquid.	
	Burns, scalding, frostbite
	● Ensure device parts, accessories and heat transfer liquid are at room temperature before touching them.

Also note the following:

- Before all maintenance work, you should ensure that decontamination of the device has been performed if it came into contact with hazardous materials.

7.2 Maintenance intervals

The maintenance intervals described in the following table must be complied with. The following maintenance work is mandatory before every longer unsupervised operation.

Interval	Maintenance work
daily	Inspection of the drain plug by visual inspection from the outside
monthly	Inspection of the external hoses for material fatigue
	Cleaning of the condenser (only air-cooled devices)
	Cleaning of the water filter (only for water-cooled devices)
quarterly	Decalcification of the cooling water circuit (a shorter interval must be selected depending on water hardness and operating time) (only for water-cooled devices)
half-yearly	Inspection of the heat transfer liquid

7.3 Cleaning the device

Personnel: ☐ Operating personnel



WARNING!
Ingress of cleaning agents in the device

Electric shock

- Use a moist cloth for cleaning.

Also note the following:

- Only clean the control panel with water and detergent. Do not use acetone or solvents. The consequence would be permanent damage of the plastic surfaces.

7.4 Cleaning air-cooled condenser

Personnel: ☐ Operating personnel

1. Switch off the device.
2. Remove the front cover by holding underneath with both hands and pulling the grating to the front. Remove the front cover slowly and carefully to prevent damage.
3. Brush off or vacuum the condenser.
4. Replace the front cover carefully.

7.5 Cleaning the water filter




Fig. 26: Removing water filter

Personnel: ■ Operating personnel

1. Switch off the device using the mains power switch.
2. Undo the union nut at the supply of the water cooling.
3. Remove the cooling water hose with the hose nozzle from the threaded connection.
4. Remove the water filter from the threaded connection carefully.



If necessary, use tweezers to remove / insert the water filter.

5. Clean the water filter and then put it back into the threaded connection.
6. Press the cooling water hose with the hose nozzle back onto the threaded connection of the supply. Carefully tighten the water hose using the union nut at the threaded connection.

7.6 Decalcification of the cooling water circuit

Personnel: ■ Operating personnel




Fig. 27: Decalcification

1. Switch off the device and prepare the decalcification process accordingly.



The descaling agent should be fed to the water cooling using a pump or a funnel through the supply hose. The descaling agent return flow should be via flow hose of the water cooling into a container with sufficient capacity (at least 10 litres).



LAUDA descaling agent (catalogue number LZB 126, 5 kg packaging) is required for decalcification. Read the safety instructions and the instructions for use on the packaging for handling the chemical.

2. Clean the water filter of the device. The water filter is in the supply of the water cooling.



Further information for cleaning the water filter can be found in ↗ Chapter 7.5 'Cleaning the water filter' on page 52.

3. Fill the supply hose of the water cooling with LAUDA descaling agent (pump or funnel). Continuously refill or pump the descaling agent. Continue this process until the foaming reaction goes down. This is usually the case after approx. 20 to 30 minutes.

4. Drain the condenser afterwards.



Further information about draining the condenser can be found in ↗ Chapter 9.2 'Draining condenser (only water-cooled devices)' on page 56.

5. Reconnect the device to the water supply and rinse it thoroughly.



Allow at least 10 litres of water to flow through the device.

7.7 Checking the heat transfer liquid

Soiled or degenerated heat transfer liquid must be replaced. Further use of the heat transfer liquid is only permitted with appropriate test results.

The heat transfer liquid must be checked according to DIN 51529.

8 Faults

8.1 Alarms, errors and warnings

Any alarms, error signals and warnings triggered on the device are shown on the display as 7-segment text.

Procedure in the event of alarms

Alarms can be cancelled using the ENTER button after rectification of the cause of the fault.

A list of alarms can be found in ↗ Chapter 8.2 'Alarms overview' on page 55.

Procedure in the event of warnings

Warnings can be cancelled using the ENTER button after rectification of the cause of the fault.

A list of warnings can be found in ↗ Chapter 8.3 'Warnings overview' on page 55.

Procedure in the event of errors

A two-tone signal is output if any error occurs. The red LED on the device also lights.

In the case of an error, switch off the device at the mains power switch. If the error occurs again after restarting the device, note the error code and contact LAUDA Service Constant Temperature Equipment. Contact details can be found in ↗ Chapter 12.3 'LAUDA contact' on page 62.



Errors are symbolised with an E and a sequential three-digit number.

8.2 Alarms overview

Alarms are relevant for safety. The components of the device such as the pump switch off. A two-tone signal is output by the device. The red LED on the device also lights.

Output on the display	Description
	In the event of a Low Level alarm, the fill level of the heat transfer liquid is below the minimum limit. The fault which caused this low fill level must be rectified to cancel the alarm. Heat transfer liquid must also be refilled. Warnings are output before the alarm is emitted. The alarm is output after approx. 5 minutes.
	The pump is blocked for any pump alarm. This can be caused by unacceptably high viscosity of the heat transfer liquid or by foreign bodies in the circuit.
	The temperature of the electronics is higher than 75 °C.

8.3 Warnings overview

Warnings are not relevant for safety. The device continues running. A continuous tone is output for a short time by the device. Warnings are output periodically. You are therefore reminded in the event of an existing fault.

Indication on the display	Description
	In the event of a Low Level warning, the fill level of the heat transfer liquid is below the minimum limit. The fault which caused this low fill level must be rectified to cancel the warning. Heat transfer liquid must also be refilled. If this warning is ignored, a Low Level alarm will be output after approx. 5 minutes and the components of the device such as the pump will be switched off.
	The upper temperature limit has been exceeded for this warning. The device fault must be rectified to remove this warning.
	The lower temperature limit has been undercut for this warning. The device fault must be rectified to remove this warning.

9 Decommissioning

9.1 Draining the device

Personnel: ☐ Operating personnel



WARNING!
Contact with cold heat transfer liquid

Frostbite

- Bring the heat transfer liquid to room temperature before draining.

Also note the following:

- Observe the regulations for disposal of the used heat transfer liquid.
1. Switch off the device.
 2. Let the device and the heat transfer liquid cool down or heat up to room temperature.
 3. Position a container with appropriate capacity directly under the drain plug.



The heat transfer liquid discharges directly from the device when the drain plug is opened.

4. Open the drain plug. Turn anticlockwise for this.

9.2 Draining condenser (only water-cooled devices)

Personnel: ☐ Operating personnel

1. Bring the device to room temperature if required and switch off the device.
2. Shut off the cooling water on the building side.
3. Unscrew the water tube from the supply nozzle of the device.
4. Remove the water filter from the threaded connection. Clean the water filter and then put it back into the threaded connection.



Further information for cleaning the water filter can be found in ↗ Chapter 7.5 'Cleaning the water filter' on page 52.

5. Unscrew the water tube from the outlet nozzle of the device.
6. Place a bucket under the outlet nozzle to collect the discharging water.

7. Without switching on the device, blow compressed air through the supply nozzle into the device. Continue blowing compressed air through the device until all the water has flowed out of the device.

10 Disposal

10.1 Disposing of refrigerant

The refrigerant must be disposed of in accordance with EC Directive 303/2008/EC in combination with 842/2006/EC.



CAUTION!
Uncontrolled escape of refrigerant

Impact, cutting

- Do not dispose of any pressurised refrigerant circuit.
- The decommissioning is only permitted by a specialist.

Refrigerant	GWP _(100a)
R134a	1430



Global Warming Potential (GWP), comparisons CO₂ = 1.0

according to IPCC IV - time horizon 100 years - also basis for EU Fluoride Gases Directive 517/2014/EC



Type and fill quantity of the refrigerant can be seen on the rating plate.

10.2 Device disposal



The following applies for Europe: The device must be disposed of according to EU Directive 2012/19/EC.

10.3 Disposing of packaging

The packaging must be disposed of in accordance with EU Directive 94/62/EC.

11 Technical data

11.1 General data



The device sound pressure level is below 70 dB. According to EC Directive 2006/42/EC, the sound pressure level of the devices is therefore not specified further.

Specification	Value	Unit
Placement	Indoor areas	
Placement height above sea level	up to 2,000	m
Humidity	Maximum relative humidity 80% at 31 °C and up to 40 °C decreasing linearly to 50%	
Ambient temperature range	5 — 40	°C
IP protection rating	IP 32	
Degree of soiling	2	
Clearance from surroundings (front and rear sides)	40	cm
Overvoltage	Overvoltage category II and transient overvoltages according to category II	
Protection class for electrical operating equipment DIN EN 61 140 (VDE 0140-1)	1	
Classification according to DIN 12 876-1 (class designation / identification)	I/NFL	
Display	7-segment, LED	
Display resolution	0.1	°C
Adjustment resolution	0.1	°C
Temperature stability	±0.5	K
Storage temperature range	5 — 40	°C
Transport temperature range	-20 — 60	°C

	Working temperature range	Dimensions (W x D x H)	Weight
	°C	mm x mm x mm	kg
MC 250	-10 — 40	200 x 350 x 465	28
MC 350	-10 — 40	240 x 400 x 500	36
MC 600	-10 — 40	350 x 480 x 595	52
MC 1200	-10 — 40	450 x 550 x 650	64
MC 1200 W	-10 — 40	450 x 550 x 650	64

Technical data

11.2 Refrigerant unit

Cooling capacity

	Unit	MC 250	MC 350	MC 600	MC 1200	MC 1200 W
Cooling capacity (for 20 °C)	kW	0.25	0.35	0.6	1.2	1.2
Cooling capacity (for 10 °C)	kW	0.2	0.28	0.5	1.05	1.05
Cooling capacity (for 0 °C)	kW	0.15	0.22	0.36	0.75	0.75
Cooling capacity (for -10 °C)	kW	0.09	0.16	0.15	0.4	0.4
Refrigerant	---	R134a	R134a	R134a	R134a	R134a



The cooling capacity is measured for a specified temperature of the heat transfer liquid. Information is provided in brackets. The ambient temperature for the measurement is 20 °C; ethanol was used as heat transfer liquid. The cooling water temperature is 15 °C and the cooling water differential pressure is 3 bar for the measurement of water-cooled devices.

11.3 Hydraulic circuit

		MC 250	MC 350	MC 600	MC 1200	MC 1200 W
Fill capacity	l	2 — 4	4 — 7	4 — 8	7 — 14	7 — 14
Maximum flow rate	l/min (water 20 °C)	16	16	35	35	35
Maximum flow pressure	bar (water 20 °C)	0.35	0.35	1.3	1.3	1.3
Pump connection	(internal diameter in mm)	Olive ½" (10)	Olive ½" (10)	G ¾ (15), olive ¾"	G ¾ (15), olive ¾"	G ¾ (15), olive ¾"
Drain tap	Connection	G ½"	G ½"	G ½"	G ½"	G ½"
Overflow connection	(internal diameter in mm)	Olive ½" (10)	Olive ½" (10)	Olive 16 mm (12)	Olive 16 mm (12)	Olive 16 mm (12)

11.4 Voltage-dependent data

Power consumption

	MC 250	MC 350	MC 600	MC 1200	MC 1200 W
	kW	kW	kW	kW	kW
230 V; 50 Hz	0.23	0.50	0.70	1.15	1.15
220 V; 60 Hz	0.23	0.50	0.70	1.15	1.15
115 V; 60 Hz	0.23	0.50	0.75	1.10	1.10
100 V; 50/60 Hz	0.23	0.50	0.75	1.10	1.10

Catalogue numbers

	MC 250	MC 350	MC 600	MC 1200	MC 1200 W
230 V; 50 Hz	LWM 118	LWM 119	LWM 120	LWM 121	LWM 122
220 V; 60 Hz	LWM 218	LWM 219	LWM 220	LWM 221	LWM 222
115 V; 60 Hz	LWM 418	LWM 419	LWM 420	LWM 421	LWM 422
100 V; 50/60 Hz	LWM 618	LWM 619	LWM 620	LWM 621	LWM 622

12 General

12.1 Copyright

This manual is protected by copyright and is exclusively intended for the purchaser for internal use.

The transfer of this manual to third parties, reproductions of any type and form, whether in whole or in part, and the dissemination and/or communication of the contents are not authorised without the written permission of the manufacturer.

Infringements will result in legal action for damages. We reserve the right to assert further claims.

12.2 Technical changes

Technical details subject to change.

12.3 LAUDA contact

Contact LAUDA Service Constant Temperature Equipment in the following cases:

- In the event of faults on the device
- For technical questions about the device
- For spare part orders

Contact our Sales Department for application-specific questions.

Contact details

LAUDA Service Constant Temperature Equipment

Telephone: +49 (0)9343 503 372

Fax: +49 (0)9343 503 283

E-Mail: service@lauda.de

12.4 EU conformity



The device complies with the basic occupational health and safety requirements of the Directives listed below.

- Machinery Directive 2006/42/EC
- EMC Directive 2004/108/EC

LAUDA DR. R. WOBSE GMBH & CO. KG - Pfarrstraße 41/43 - 97922 Lauda-Königshofen - Germany



The device does not come under the Pressure Equipment Directive 2014/68/EC as the device is classified in maximum category 1 and is covered by the Machinery Directive.

13 Index

A

Air-cooled	
Cleaning condenser	51
Alarm	
Codes	55
Description	54
Arrow buttons (position)	18

C

Calibration (actual temperature)	
Specifying	48
Checking	
Heat transfer liquid	53
Classification (EMC)	23
Cleaning	51
Code	
Alarms	55
Conformity (EU)	62
Cooling water	
Connecting	29
Pressure	29
Requirements	27
Temperature	29
Copyright	62

D

Demineralised water	32
Design	
Device	14
Device	
Cleaning	51
Design	14
Disposal (packaging)	58
Disposal (refrigerant)	58
Draining	56
Draining condenser (water-cooled)	56
Filling	33
Placement	24
Unpacking	11
Display buttons	
Operation	18
Disposal	
Packaging	58
Refrigerant	58
Disposing of refrigerant	58
DM water	32
Draining	
Condenser (water-cooled)	56
Device	56

E

EMC classification	23
ENTER button (position)	18

Error

Description	54
Establishing power supply	33
EU conformity	62
External consumer	
Connecting	27

F

Factory settings	
Overview	49
Restoring	49
Fill level	
drops	33
low	33
Filling	33

H

Heat transfer liquid	
Checking	53
Removing	56
Heat transfer liquids	
Overview (approved)	32
Hydraulic circuit	
Description	19

I

Intended use	7
--------------	---

L

LAUDA heat transfer liquids	32
LAUDA Service Constant Temperature Equipment	
Address	62
Contact	62
LED, yellow	40

M

Machine	
Cleaning condenser (air-cooled)	51
Machinery Directive	62
Mains power (connection)	33
Mains power switch	
Operation	17
Maintenance	
Intervals	50
Manometer	
Description	20

O

Offset (actual temperature)	
Calibration	48
Overflow connection	
Tube	33
Overflow tube	33

Index

P	
Packaging	
Disposal	58
Personal protective equipment (overview)	9
Personnel qualification (overview)	8
Placement (device)	24
Placement location	24
Protective equipment (personal, overview)	9
Pump pressure	
setting	36
R	
Rating plate	14, 22
S	
Safety instruction	
General	6
Service (LAUDA, Temperature Equipment)	62
Specifying limit values (temperature)	41
Specifying temperature limit values	41
Specifying the setpoint	40
Specifying the setpoint temperature	40
T	
Technical changes	62
U	
Unpacking	11
W	
Warning	
Description	54
Water-cooled	
Draining condenser	56
Y	
yellow LED	40

An / To / A:

LAUDA Dr. R. Wobser • LAUDA Service Center • Fax: +49 (0) 9343 - 503-222

Von / From / De :

Firma / Company / Entreprise: _____

Straße / Street / Rue: _____

Ort / City / Ville: _____

Tel.: _____

Fax: _____

Betreiber / Responsible person / Personne responsable: _____

Hiermit bestätigen wir, daß nachfolgend aufgeführtes LAUDA-Gerät (Daten vom Typenschild):

We herewith confirm that the following LAUDA-equipment (see label):

Par la présente nous confirmons que l'appareil LAUDA (voir plaque signalétique):

Typ / Type / Type :	Serien-Nr. / Serial no. / No. de série:

mit folgendem Medium betrieben wurde

was used with the below mentioned media

a été utilisé avec le liquide suivant

Darüber hinaus bestätigen wir, daß das oben aufgeführte Gerät sorgfältig gereinigt wurde, die Anschlüsse verschlossen sind, und sich weder giftige, aggressive, radioaktive noch andere gefährliche Medien in dem Gerät befinden.

Additionally we confirm that the above mentioned equipment has been cleaned, that all connectors are closed and that there are no poisonous, aggressive, radioactive or other dangerous media inside the equipment.

D'autre part, nous confirmons que l'appareil mentionné ci-dessus a été nettoyé correctement, que les tubulures sont fermées et qu'il n'y a aucun produit toxique, agressif, radioactif ou autre produit nocif ou dangereux dans la cuve.

Stempel Seal / Cachet.	Datum Date / Date	Betreiber Responsible person / Personne responsable

LAUDA DR. R. WOBSE R GMBH & CO. KG
Pfarrstraße 41/43 • 97922 Lauda-Königshofen • Germany
Phone: +49 (0)9343 503-0 • Fax: +49 (0)9343 503-222
E-Mail: info@lauda.de • Internet: www.lauda.de